



### KAWASAKI 2013-14 Teryx 750 | 2014-20 Teryx 800 2" Lift Kit

**Thank you for choosing Rough Country for all your vehicle needs.**

Rough Country recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Check the kit hardware against the parts list. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools. If question exist, please call us @1-800-222-7023. We will be happy to answer any questions concerning this product. Check all fasteners for proper torque. Check to ensure for adequate clearance between all components. Periodically check all hardware for tightness.

#### PRODUCT USE INFORMATION

**▲WARNING** The taller a vehicle is, the easier it will roll. We strongly recommend, because of rollover possibility that seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur.

**▲WARNING** Generally, braking performance and capability are decreased when larger/heavier tires and wheels are used. Take this into consideration while driving. Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands is not recommended.

Rough Country makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any product that is altered. If questions exist we will be happy to answer them concerning the design, function, and correct use of our products.

#### ▲NOTICE DEALER AND VEHICLE OWNER

Any vehicle equipped with any Rough Country product should have a "Warning to Driver" decal installed on the inside of the windshield or on the vehicle's dash. The decal should act as a constant reminder for whoever is operating the vehicle of its unique handling characteristics.

#### Torque Specs:

Size	Grade 5	Grade 8	Size	Class 8.8	Class 10.9
5/16"	15 ft/lbs	20ft/lbs	6MM	5ft/lbs	9ft/lbs
3/8"	30 ft/lbs	35ft/lbs	8MM	18ft/lbs	23ft/lbs
7/16"	45 ft/lbs	60ft/lbs	10MM	32ft/lbs	45ft/lbs
1/2"	65 ft/lbs	90ft/lbs	12MM	55ft/lbs	75ft/lbs
9/16"	95 ft/lbs	130ft/lbs	14MM	85ft/lbs	120ft/lbs
5/8"	135ft/lbs	175ft/lbs	16MM	130ft/lbs	165ft/lbs
3/4"	185ft/lbs	280ft/lbs	18MM	170ft/lbs	240ft/lbs



**KIT CONTENTS:**

Front Bracket x1  
Rear Brackets x4

**TOOLS NEEDED:**

17mm Socket/Wrench  
19mm Socket/Wrench  
9/16" Socket/Wrench  
Drill  
5/16" Drill Bit


**HARDWARE INCLUDED:**

10mm x 70mm Bolts x4  
10mm Lock Nuts x4  
12mm x 70mm Bolts x4  
12mm Lock Nuts x4  
3/8" x 1" Bolts x4  
3/8" Lock Nuts x4  
3/8" Flat Washers x8  
3/4" x 1.27" Sleeves (Front) x2  
3/4" x 1.37" Sleeves (Rear) x2




## FRONT INSTALLATION INSTRUCTIONS



1. Lift up the front of the vehicle and place on jack stands. Remove the front wheels.
2. Remove the front upper strut bolt using two 19mm socket/wrenches. **See Photo 1.**
3. Remove the air filter cover. **See Photo 2.**




4. Place the front bracket across Dr and Pass side strut locations and move the air filter clamp out of the way when installing. **See Photo 3 and Photo 4.**




5. Unplug radiator hose and reroute over the front bracket. **See Photo 5.**
6. Install 3/4" x 1.27" spacer sleeves in the upper strut locations with the supplied 12mm bolt, nut, and washers (install washers on the outside of the bracket) using two 19mm socket/wrenches. **See Photo 6.**



7. Install the strut in the front bracket using the supplied 12mm hardware (install the washers between the strut and brackets). **See Photo 7.**
8. Tighten the Dr and Pass side using two 19mm socket/wrenches. **See Photo 8.**



**Install strut in bracket with washers between.**




**Tighten Dr and Pass side.**


9. Put on wheels and lower.

### REAR INSTALLATION INSTRUCTIONS

1. Jack up the rear of the vehicle and place on jack stands. Remove rear wheels.
2. Remove the rear lower strut bolt using two 17mm socket/wrenches. **See Photo 1.**
3. Install the rear brackets and the strut in the stock mount locations with the supplied 10mm hardware and 3/4" x 1.37" spacer sleeve using two 17mm socket/wrenches. **See Photo 2.**




**Remove rear lower strut bolt.**




**Install rear brackets and strut.**

4. Drill through the lower hole in the bracket using a 5/16" drill bit. **See Photo 3.**
5. Install the 3/8" hardware in the drilled hole using a 9/16" socket/wrench. **See Photo 4.**



**Drill through hole in bracket.**



**Install 3/8" hardware in drilled hole.**

6. Put on wheels and lower.

By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

